

Model 3615-L2A
6-channel, 100 MHz Counter
INSTRUCTION MANUAL

October, 1988

(C) 1977, 1987, 1988
Copyright by
KineticSystems Corporation
Lockport, Illinois
All rights reserved

**** SPECIAL OPTION ****

MODEL 3615-S002

6-CHANNEL, 100 MHZ COUNTER

DECEMBER 1984

Model 3615-S002

**** SPECIAL OPTION ****


Model 3615-S002

The Model 3615-S002 is a 3615-L2A with all integrated circuits loaded in sockets.

TABLE OF CONTENTS

<u>Item</u>	<u>Page</u>
Features and Applications	1
General Description	1
Function Codes	1
Simplified Block Diagram	2
Power Requirements	2
Ordering Information	2
Front Panel Description	3
Input Signal Description	4
Module Straps	4
Figure 1 - Strap Locations	5
I/O Connector Wiring	6
WARRANTY	7
Schematic Drawing #02244-D-4022 (2 pages)	

Simplified Block Diagram



Power Requirements

+6 volts: 1200 mA

Ordering Information

Model 3615-L2A 100 MHz Counter, 6 channels, 24 bits, LEMO connectors

Related Products

Models 5910-Z1A, 5960-Z1A, or 5960-Z1B
 Models 5857-Axyz and 5857-Bxyz
 Model 3655-L1A

Mating Connectors
 I/O Cables
 Timing Pulse Generator, 8 channels, with LEMO connectors

FRONT PANEL DESCRIPTION

- N This LED flashes momentarily when the module is addressed.
- LE This LED is lit when the LAM request has been enabled by the F(26).A(0) command.
- LS This LED is lit when any of the channels have set the LAM source by overflowing the counters.
- CE This LED is lit when the module is enabled to count. Either a Dataway Inhibit or an Inhibit signal from the front panel connector will disable the module from counting.
- Inhibit Switch Dataway Inhibit enable/disable switch. In the up (EN) position, the Dataway Inhibit will disable counting when the Inhibit signal is true. In the down position, the Dataway signal will have no effect. This switch has no effect on the front panel inhibit signal.

Single Pin LEMO connectors:

- 0-5 These six LEMO connectors are the inputs to channels 0 through 5. Channel 0 is accessed through subaddress A(0) for F(0), F(2), F(9) and F(10) function codes. Similarly, Channel 1 through Channel 5 will have subaddresses A(1) through A(5), respectively.
- C Two LEMO connectors for the external clear signal. The external clear signal is a low-true TTL level signal which clears all six counters and overflow bits. Two connectors are provided for 'daisy chaining'.
- I Two LEMO connectors used for inhibiting counting with a NIM level negative voltage. Two connectors are provided for 'daisy chaining'. A 50 ohm termination should be connected to the spare Inhibit input on the last 3615. These inhibit inputs are independent of the Dataway Inhibit switch.

INPUT SIGNAL DESCRIPTION

Channels 0-5 accept NIM standard signals at the front panel connector. These inputs are terminated in 50 ohms. A logical 1 occurs when an output is sinking 16 mA from the input. A logical 0 is represented by the output, that is driving the input, not sinking any current. In a logical 1 state the input (at the 50 ohm resistor) will be forced to -0.8 volts ($50 \text{ ohms} \times (-16\text{mA})$) while a logical 0 will approximately be at ground potential. The input threshold of the module is approximately -0.4 volts.

MODULE STRAPS

Six straps, one for each channel, are provided for the user to select if the LAM status is set on the overflow of either 16 or 24 bits. These straps are located in the middle of the board with channel 0 at the bottom of the column and channel 5 at the top. Each channel is selected independently of the others. With the strap in location G, the LAM status will be set on the overflow of 24 bits, while location H is used for selecting 16 bit overflow.

For each of the channels, three straps are provided so the overflow output of one channel can pulse the input of another channel.

Loading strap A will connect the overflow bit to the 36-pin rear I/O edge connector. Moving this strap to location B will disconnect this signal from the edge connector.


Loading strap C will connect the overflow bit to the wire-or LAM source, while with the strap in location D, the overflow bit will be disconnected from this wire-or. When it is desirable to pulse the overflow bit (see below), the strap should be loaded in location D.

Strap location F is used to pulse the overflow bit. When the overflow bit gets set, from either a 16 or 24 bit carry, this strap feeds back the overflow bit through an R-C network to clear itself. Thus initiating a 200 nanosecond pulse. Strap E is loaded for normal operation of the 3615 when the LAM source is used.


Summary: Load straps A, D, and F for each channel to output a pulse on an overflow.

 Load straps B, C, and E for normal LAM status operation.

Refer to Figure 1 for strap locations.



STRAP LOCATIONS
FIGURE 1



Pin/Wire List

18/36 POSTION P.C. EDGE

FACE VIEW

<u>PIN NO.</u>	
1R	GND
2R	GND
3R	Channel 5 Overflow-NIM
4R	Channel 4 Overflow-NIM
5R	Channel 3 Overflow-NIM
6R	Channel 2 Overflow-NIM
7R	Channel 1 Overflow-NIM
8R	Channel 0 Overflow-NIM
9R	
10R	
11R	
12R	
13R	
14R	
15R	
16R	
17R	
18R	

<u>PIN NO.</u>	
1	GND
2	GND
3	Channel 5 Overflow-TTL
4	Channel 4 Overflow-TTL
5	Channel 3 Overflow-TTL
6	Channel 2 Overflow-TTL
7	Channel 1 Overflow-TTL
8	Channel 0 Overflow-TTL
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	

WARRANTY

KineticSystems Company, LLC warrants its standard hardware products to be free of defects in workmanship and materials for a period of one year from the date of shipment to the original end user. Software products manufactured by KineticSystems are warranted to conform to the Software Product Description (SPD) applicable at the time of purchase for a period of ninety days from the date of shipment to the original end user. Products purchased for resale by KineticSystems carry the original equipment manufacturer's warranty.

KineticSystems will, at its option, either repair or replace products that prove to be defective in materials or workmanship during the warranty period.

Transportation charges for shipping products to KineticSystems shall be prepaid by the purchaser, while charges for returning the repaired warranty product to the purchaser, if located in the United States, shall be paid by KineticSystems. Return shipment will be made by UPS, where available, unless the purchaser requests a premium method of shipment at their expense. The selected carrier shall not be construed to be the agent of KineticSystems, nor will KineticSystems assume any liability in connection with the services provided by the carrier.

The product warranty may vary outside the United States and does not include shipping, customs clearance, or any other charges. Consult your local authorized representative or reseller for more information regarding specific warranty coverage and shipping details.

PRODUCT SPECIFICATIONS AND DESCRIPTIONS IN THIS DOCUMENT SUBJECT TO CHANGE WITHOUT NOTICE.

KINETICSYSTEMS SPECIFICALLY MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY EITHER EXPRESSED OR IMPLIED, EXCEPT AS IS EXPRESSLY SET FORTH HEREIN. PRODUCT FAILURES CREATED BY UNAUTHORIZED MODIFICATIONS, PRODUCT MISUSE, OR IMPROPER INSTALLATION ARE NOT COVERED BY THIS WARRANTY.

THE WARRANTIES PROVIDED HEREIN ARE THE PURCHASER'S SOLE AND EXCLUSIVE REMEDIES ON ANY CLAIM OF ANY KIND FOR ANY LOSS OR DAMAGE ARISING OUT OF, CONNECTED WITH, OR RESULTING FROM THE USE, PERFORMANCE OR BREACH THEREOF, OR FROM THE DESIGN, MANUFACTURE, SALE, DELIVERY, RESALE, OR REPAIR OR USE OF ANY PRODUCTS COVERED OR FURNISHED BY KINETICSYSTEMS INCLUDING BUT NOT LIMITED TO ANY CLAIM OF NEGLIGENCE OR OTHER TORTIOUS BREACH, SHALL BE THE REPAIR OR REPLACEMENT, FOB FACTORY, AS KINETICSYSTEMS MAY ELECT, OF THE PRODUCT OR PART THEREOF GIVING RISE TO SUCH CLAIM, EXCEPT THAT KINETICSYSTEMS' LIABILITY FOR SUCH REPAIR OR REPLACEMENT SHALL IN NO EVENT EXCEED THE CONTRACT PRICE ALLOCABLE TO THE PRODUCTS OR PART THEREOF WHICH GIVES RISE TO THE CLAIM. IN NO EVENT SHALL KINETICSYSTEMS BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING LOSS OF PROFITS.

Products will not be accepted for credit or exchange without the prior written approval of KineticSystems. If it is necessary to return a product for repair, replacement or exchange, a Return Authorization (RA) Number must first be obtained from the Repair Service Center prior to shipping the product to KineticSystems. The following steps should be taken before returning any product:

1. Contact KineticSystems and discuss the problem with a Technical Service Engineer.
2. Obtain a Return Authorization (RA) Number.
3. Initiate a purchase order for the estimated repair charge if the product is out of warranty.
4. Include a description of the problem and your technical contact person with the product.
5. Ship the product prepaid with the RA Number marked on the outside of the package to:

KineticSystems Company, LLC
Repair Service Center
900 North State Street
Lockport, IL 60441

Telephone: (815) 838-0005
Facsimile: (815) 838-4424
Email: tech-serv@kscorp.com